

## Magic Brake Strobe™

1. Locate brake wire and cut in half
2. Connect Red Wire to Input Side using Posi-Lock.
3. Connect White Wire to Output (brake light) Side using Posi-Lock (both ends same color).
4. Connect Black Wire to Ground using Posi-Tap (has gray end).
5. Secure unit with enclosed tie wraps
6. Select Desired Pattern with Power Off
7. Check Operation
8. To change Mode, turn bike off and change dial to desired pattern.

**NOTE:** for operation of Posi-Lock and Posi-Tap, see [www.posi-lock.com](http://www.posi-lock.com)

Pattern 0: Four Flashes then Solid (Incandescent or LED)

Pattern 1: Four Flashes, Solid for 3 Seconds, Repeat (Incandescent or LED)

Pattern 2: Seven Flashes then Solid (Incandescent or LED)

Pattern 3: Seven Flashers, Solid for 3 Seconds, Repeat (Incandescent or LED)

Pattern 4: Quad Strobe then Solid for 1 Second then Quad Strobe (LED Only)

Pattern 5: Quad Strobe, Solid for 1 Second, then Quad Strobe, Solid for 3 Seconds, Repeat (LED Only)

Pattern 6: Blaster X Pattern for 3 seconds, then Solid (LED Only)

Pattern 7: Constant Blaster X Pattern (LED Only)

Pattern 8: Constant Fast Strobe 5 Seconds, then Solid (LED Only)

Pattern 9: Constant Fast Strobe Pattern (LED Only)

